

DIRECTIONS 849

- STEP #1.** **The car must rest on its springs on level ground.**
- STEP #2.** **Remove factory anti-sway bar and brackets.**
- STEP #3.** **Position the bar on the cross-frame and secure with the two-piece brackets. The bolt holding the two parts of the bracket should be secured last.**
- STEP #4.** **Assemble brackets around McPherson struts and bolt the ends of the bar to them as shown in the drawing.**
- STEP #5.** **The kit is now installed. Check all fastenings for tightness. Have someone bounce the car so you can check for clearance of all equipment throughout the suspension travel distance. Road test the car to familiarize yourself to its new handling. As we cannot supervise your installation or driving, we cannot be held responsible for more than the cost of the kit.**

HARDWARE

2 UB 613B Bushings
4 RH 304 Lock-Nuts
2 RH 213 Bolts
2 RH 214 Bolts
2 RH 611B Bushings
2 RH 707 Plates
2 RH 042B Brackets
2 RH 053 Brackets
4 RH 104 Washers

DIRECTION 849

